

EXOTRONIC

Electronics for the Great Outdoors

Pre-wired Battery Box



Warning

To maximise the longevity and safety of your new Exotronic Pre-Wired Battery Box, please ensure you follow stay within the specified parameters and connect to the appropriate terminals referring to the wiring diagram. Failure to do so could result in shortened lifespan and void your warranty.

Risk of fire/explosion – do not short circuit the equipment or exceed voltages. Always check polarity before powering equipment on. Do not expose to the weather or allow water ingress. Keep out of excess dust and do not exceed temperature ratings. Always select appropriate fuse sizes and ensure suitably tight connections.

DC-DC Charging

The DC-DC is set to 35A by default, but can be set up to 50A, providing it is installed under suitable environmental conditions.

Solar Charging

Capable of charging up to 15A and configurable via Bluetooth.

Smart Shunt

300A Battery monitor providing detailed usage insights via the VictronConnect app.

Wiring Diagram

